


BSNL

LANDLINE



USER MANUAL

UTL-81B CLIP PHONE


I. INTRODUCTION

UTL 81B – is extremely reliable integrated telephone system. It has three line 16 digit display with instruction to take you through all the operating procedures. It has wide range of functions, including phone book, caller ID, back light and speaker phone with enhanced voice clarity.

II. FEATURES

- ❖ FSK/DTMF Dual Mode Caller ID
- ❖ LCD with Backlight Function.
- ❖ 99 Incoming calls Memory
- ❖ 10 Outgoing Calls Memory
- ❖ 50 Phone Book Memory
- ❖ 3 One touch Memory
- ❖ 10 Two touch Memory
- ❖ 16 Digit LCD Display for Name and Number
- ❖ Real Time Clock, Date, Month and year.
- ❖ Two way speaker phone with volume adjustment
- ❖ Flash, Mute and redial function.
- ❖ Local area code setting.
- ❖ Long distance code setting.
- ❖ Low battery indication
- ❖ Intelligent back light.
- ❖ Displays Incoming number, new call, total calls, repeat calls.
- ❖ Wall mountable
- ❖ Visual Ringer lamp.

Parts Checklist




Installation

Installing and replacing batteries


UTL-81B requires three AA size batteries for backlight.

- Disconnect the telephone line cord before installing and replacing batteries.
- Remove the battery compartment cover.
- Insert three AA batteries.
- Replace the battery compartment cover and press to lock.





Installing the Telephone

1. Insert one end of the telephone line cord into the telephone line socket and the other end to the phone socket marked 'LINE' at the bottom of the base unit.
2. Insert one end of the handset coil cord into the handset and the other end to the modular jack on the bottom of the base unit.





Wall Mounting Installation


1. Insert mounting screw. Allow about 5mm between the wall and screw heads for mounting the phone.
2. Gently remove and turn the handset retainer tab 180° and replace.
3. Place the base unit on the screws and push down until it's firmly seated.








Base Layout



LCD Display layout



1		Speakerphone
2		Low battery indicator
3	IN	Incoming call
4	OUT	Outgoing call
5		Number of calls
6	NEW	New CID
7	REP	Repeat
8		Time
9		Date
10	AM	Morning
11	PM	Afternoon

1. Menu Settings

Key Operation	Display on LCD	Description
Press 'SET' Key	SET CLOCK?	Used to set the time/date/month/year
Press 'SET' Key & 'UP' key once	SET AREA CODE?	Used to set the local area code
Press 'SET' Key & 'UP' key twice	SET LONG CODE?	Used to set the long distance code
Press 'SET' Key & 'UP' key three times	SET FLASH TIME?	Used to program the flash time
Press 'SET' Key & 'UP' key four times	SET PASSWORD?	Used for call restrict function
Press 'SET' Key & 'UP' key five times	SET RESTRICT?	Used to lock dialing of '0' & '95'
Press 'SET' Key & 'UP' key six times	SET BABY CALL?	Used to set the baby call
Press 'SET' Key & 'UP' key seven times	SET LCD CONT.?	Used to set the required level of contrast for the LCD

Characters

Key	Characters
1	*,#,+,1
2	A B C 2
3	D E F 3
4	G H I 4
5	J K L 5
6	M N O 6
7	P Q R S 7
8	T U V 8
9	W X Y Z 9
*	*
0	0, Space
#	#

OPERATING INSTRUCTION

Making a Call

There are three modes to make a call.

1. Using Handset

Pick up the handset and hear the dial tone.

Press the desired number and speak to the other end.

After the conversation, replace the handset on the base.

2. Using Pre-dialing

When the handset is on the base, dial the desired number.

If the number is stored in the phone book, then the LCD will display the name of the number.

Go OFF HOOK or Press Hands free key.

Speak to the other end by lifting the handset.

After the conversation, replace the handset on the base.

3. Using Hands free

When the handset is on the base, press the hands free key.

You will get the dial tone in the speaker.

Press the desired number and speak.

After the conversation press the handsfree key to disconnect.

4. **Set Long Distance Code to '0----**

Press 'Redial' Button Twice To dial out STD numbers

(Mobile / Landline) from 'Received call list.

Receiving a Call

When your phone rings, pick up the handset. Speak to the other end.

Speaker Volume Adjustment

Press [VOL] key to adjust the SPK volume during Hands Free.

Flash (FLASH KEY)

Pick up the handset, press the FLASH key, the phone line will break for 300ms*(Default setting is 300ms, and you can select flash timing other than 300ms, from 100ms to 1000ms)

Last Number Redial

Pick the handset and press the Redial key, the last number will be automatically dialed out.

Mute

When MUTE key is pressed once, MUTE will be activated and MUTE will be displayed on LCD. No speech will be transmitted to the other party during mute. To deactivate, press MUTE key again.

Secret Dialing

In the off-hook state, press 'DEL/SECRET' once to activate secret dialing function. LCD displays "-" for every number input. Not stored, and cannot be redialed. To deactivate it, press 'DEL/SECRET' again.

Low Battery Indicate

When low battery, an indicator will display on LCD to indicate user to change battery in time.

Caller Timer

LCD displays 'USED: 00:00:00' when hook off. And counter to 59:59:59 maximum. Manual timer is invalid.

T/P Switcher

1. Using T/P switch set the dialing mode.
2. Press '**' button to get the temporary change over from Pulse to Tone.

Time to Default Mode

1. 1min to go back to default mode after viewing CLI, outgoing calls or New call incoming
2. 15seconds to go back to default mode after other operations.

Checking Outgoing Calls (Dialed number)

1. Press the 'OUT' key when handset is on the base.
2. LCD screen will display the last dialed number with conversation time.
3. To view more outgoing numbers (Max. 10), press 'OUT' key again.
4. All the numbers in outgoing memory will be displayed.

Checking Incoming Calls (LIFO)

5. When handset is on the base, press 'UP' / 'DOWN' key.
6. LCD display the incoming number and name.
7. The CLI displayed with 'NEW' tag if the call is missed call*.
8. To view more incoming calls (Max. 99), press 'UP' or 'DOWN' key.
9. All the numbers and names of CLI will be displayed.

Missed Call * : If incoming call is not attended (i.e. no one has lifted the handset or press the 'H/F' key during ringing). The CLI number is stored in the incoming numbers memory with tag 'NEW' indicating the calls is missed and not attended. When checking incoming calls, the call which is missed will be displayed with 'NEW' tag.

Once the CLI is checked, the 'NEW' tag will disappear and number (with name) will remain stored in the incoming call memory as received calls.

The no. of times the call is received will be indicated by a number near 'NEW' tag. So, for the first will be taken as Zero, second as one, and so on. After 10 calls, suffix P will come after NEW tag, and no. of total calls will go on increasing.

Erasing Outgoing Calls

1. Press the 'OUT' key, when the handset is on the base.
2. LCD displays the last dialed number.
3. Press the 'DEL' key for more than 3s, CLEAR ALL CALLS will appear on the LCD, Press DEL again 'ALL CLEARED!' will appear on the LCD.

Erasing Incoming Calls

1. Press 'UP' or 'DOWN' key to get the desired CLI when handset is on the base.
2. Press 'DEL' key, 'CLEARED!' will appear on the LCD. Or press 'DEL' key for more than 3s, 'ALL CLEARED!' will appear on the LCD.

Storing number in One-touch Memory

1. When handset is on the base, dial desired number (or the desired incoming call or outgoing call) to be stored & press the 'SET' key
2. LCD displays 'PLS INPUT NAME' for 1 second, and indicate user to enter name
3. After entering name, press the memory button, i.e.M1,M2, M3 where you would like to store the number.
4. LCD will display 'STORE MEMORY?'
5. Press any memory button twice, i.e. M1, M2, M3 and the LCD will confirm 'STORED' for 1 second.
6. If number stored is already stored in the memory, LCD will display 'OVER WRITE?', press Mi (i=1,2,3) key will overwrite, or press 'FLASH' to exit.

Storing number in Two-touch Memory

1. When handset is on the base, dial desired number (or the desired incoming call or outgoing call) to be stored & press the 'SET' key
2. LCD display 'PLS INPUT NAME' for 1 second, and indicate user to enter name
3. After entering name the, press 'PICKUP' key, LCD will display 'ENTER LOCA. 0-9'
4. Press the location from 0-9 where you would like to store the number.
5. LCD will display 'STORE MEMORY?'
6. Press the location again, and the LCD will confirm 'STORED' for 1 second.
7. If there has number stored in the memory, LCD will display 'OVER WRITE?', press the desired location number again will overwrite, or press 'FLASH' to exit.

Dialing from One-touch Memory

1. Pick up the handset or press the 'HANDS FREE' key for off-hook.
2. Listen the dial tone & press the memory button M1 (or M2, M3) which you want to dial.

3. Then number in memory will be displayed and dialed out and the name also will be displayed on the LCD.
4. Get the desired One-touch memory in on-hook mode, press 'REDIAL' or 'HANDS FREE' key or pick up handset will dial out the number. Press 'REDIAL' twice will dial long distance code before the displayed number.
5. If no number stored in memory, LCD will display 'CALL EMPTY!' for 1 second.

Dialing from Two-touch Memory

1. Pick up the handset or press the 'HANDS FREE' key for off-hook.
2. Press 'PICKUP', LCD will display 'ENTER LOCA. 0-9'
3. Press any memory desired from 0-9
4. The number stored in the memory will be displayed and dialed out and the duration time will be displayed on the LCD.
5. Get the desired Two-touch memory in on-hook mode, press 'REDIAL' or 'HANDS FREE' key or pick up handset will dial out the number. Press 'REDIAL' twice will dial long distance code before the displayed number.
6. If no number stored in memory, when dialing, LCD will display 'CALL EMPTY!' for 1 second.

Phone Book Input

1. Press 'PHONE BK' in on-hook mode, LCD will display 'INPUT↑ SEARCH↓'.
2. Press 'UP' to enter the name edit mode, LCD will display 'PLS INPUT NAME', Using 'DEL' to delete wrong character. Max. 16 characters.
3. After entering name, press 'PHONE BK' to enter the number edit mode, LCD will display 'PLS INPUT NUMBER', Using 'DEL' to delete the wrong number. Max. 16 numbers.
4. After entering number, press 'PHONE BK' twice to confirm.
5. If the memory is full, LCD will display 'MEMORY FULL'. Press 'PHONE BK' twice or press 'FLASH' or 'SPK' to exit.
6. When handset is on the base, dial desired number (or the desired incoming call or outgoing call) to be stored & press the 'SET' key
7. LCD display 'PLS INPUT NAME' for 1 second, and indicate user to enter name
8. After entering name, press 'PHONE BK' key, LCD will display 'STORE PHONE BK?'
9. Press 'PHONE BK' again and the LCD will confirm 'STORED' for 1 second.

Phone Book Checking and Editing:

1. Press 'PHONE BK' either in off-hook or on-hook mode, LCD will display 'INPUT↑ SEARCH↓'.
2. Press 'DOWN' to enter the searching mode. LCD will display 'PLS INPUT NAME'. Press 'UP' or 'DOWN' to view the PHONE BK items one by one. Or enter the name by pressing character button. If there is no item beginning with the character you enter, then the LCD will display 'END OF LIST!'. You can go on pressing button for the desired one.
3. When you get the desired phone book item, press 'PHONE BK' to modify it.
4. Modify the name if necessary. Then press 'UP' to modify the number.
5. After modification, Press 'PHONE BK', LCD will display 'STORE PHONE BK?', press 'PHONE BK' again, LCD will display 'OVER WRITED?'
6. Press 'PHONE BK' again to confirm, then LCD will display 'STORED!'

Dialing from Phone Book

1. Get the desired phone book number in the on-hook mode, and the name also will be displayed on the LCD.
2. Press 'REDIAL' or 'HANDS FREE' key or pick up handset will dial out the number. Press 'REDIAL' twice will dial long distance code before the displayed number.

Erasing Phone Book

1. Get the desired phone book number in the on-hook mode, and the name also will be displayed on the LCD.
2. Press 'DEL', LCD will display 'CLEAR THE CALL?'
3. Press 'DEL' again to delete the item, LCD will display 'CLEARED!'

Procedure for 'SET' Functions

Set Clock

1. Press 'SET' key once in the on-hook mode, LCD will display 'SET CLOCK?'
2. Press 'SET' again, the year number will blink on the LCD.
3. Press Number keys to change the year number.
4. Press 'SET' to confirm, and the month number will blink
5. Press Number keys to change the year number.
6. Press 'SET' to confirm, and the date number will blink.
7. Set the number of year, month, date, hour, minute, AM and PM one by one. Then press 'SET' to confirm.

Set Local Area Code

1. Press 'SET' key and then press 'UP' key once or press 'DOWN' 8 times in the on-hook mode, LCD will display 'SET AREA CODE?'
2. Press 'SET' key again, LCD will display 5 ' - 's on the segment area.
3. To Enter Area Code use Number keys Eg. **For Bangalore 80.**
4. Press 'SET' to confirm

Set Long Distance Code

1. Press 'SET' key and then press 'UP' key twice or press 'DOWN' 7 times in the on-hook mode, LCD will display 'SET LONG CODE?'
2. Press 'SET' key again, LCD will display '0 - - ' on the segment area.
3. To Enter Long Dist code Use Number keys Eg. **Enter 0.**
4. Press 'SET' to confirm.

Set Flash Time

1. Press 'SET' key and then press 'UP' key three times or press 'DOWN' 6 times in the on-hook mode, LCD will display 'SET FLASH TIME?'
2. Press 'SET' key again, LCD will display 'FLASH TIME 300ms' as the default flash time, and the number is blinking.
3. Press 'UP' or 'DOWN' to select the desired time from 100ms to 1000ms.
4. Press 'SET' key to confirm.

Set Password

1. Press 'SET' key and then press 'UP' key four times or press 'DOWN' 5 times in the on-hook mode, LCD will display 'SET PASSWORD?'
2. Press 'SET' key again, LCD will display 'NEW PASSWORD'
3. Press Number keys to set the new Password up to 4 digits
4. Press 'DEL' to delete the wrong number.
5. Press 'SET' again to confirm.
6. If you want to change your Password, after the step 1, and press 'SET', LCD will display 'CURRENT PASSWORD'
7. Enter the current Password by pressing the digital button 0-9.
8. Press 'SET' to confirm.
9. If the entered Password is wrong, LCD will display 'ERROR' for 1s, and then display 'CURRENT PASSWORD' again.
10. If the Password is correct, then LCD will display 'NEW PASSWORD'
11. Press the new 4-digit Password and confirm it by 'SET'
12. If you want to clear the Password when you knowing the Password, when proceed to step 9, you can press 'SET' directly without entering any number. Or proceed the step 13 directly.
13. If you forget the Password, press “*#0000#” in the on-hook mode to clear the Password.

Set Restrict No.

1. Press 'SET' key and then press 'UP' key five times or press 'DOWN' 4 times in the on-hook mode, LCD will display 'SET RESTRICT?'
2. Press 'SET' key again, LCD will display 'ENTER PASSWORD'
3. Press Number keys to enter the Password up to 4 digits
4. Press 'SET' key again to set the restrict no.
5. LCD will display 'RESTRICT OFF', press 'UP' or 'DOWN' to be ON.
6. Press 'SET' key again to set the no. up to 16 digits, 0 & 95 are the default restrict no.
7. Press 'Pause' to enter P between two restrict numbers.
8. Press 'SET' key to confirm.
9. After setting the restrict ON, and setting the restrict numbers, the number you try to dial out which beginning with the restrict numbers will not be able to dialed out. At this moment, you need to enter the Password. Only when the Password is correct the numbers will be displayed and dialed out.

Set Baby Call

1. Press 'SET' key and then press 'UP' key six times or press 'DOWN' 3 times in the on-hook mode, LCD will display 'SET BABYCALL?'
2. Press 'SET' key again, LCD will display the state of this function. 'BABYCALL OFF'.
3. Press 'UP' or 'DOWN' to be baby call ON.
4. Press 'SET' key to confirm.
5. LCD will display 'PLS INPUT NUMBER' in the dot-matrix area.
6. Press Number keys to enter the baby call number, up to 16 digits.
7. Press 'SET' key to confirm.
8. After setting and exit the menu mode, press any key except 'SET' or pick up the handset will dial out the baby call number directly.

Set LCD Contrast

1. Press 'SET' key and then press 'UP' key seven times or press 'DOWN' 2 times in the on-hook mode, LCD will display 'SET LCD CONT.?'
2. Press 'SET' key again, LCD will display 'LCD CONTRAST 3' in the dot-matrix area, with the number blinking.
3. Press 'UP' or 'DOWN' to select the desired contrast level. There are 5 levels, Level 3 is the default.
4. Press 'SET' key to confirm.

UNITED TELECOMS LIMITED
18A/19, Doddanekundi Industrial Area,
Mahadevapura Post, Bangalore,
PIN: 560048
Ph: 080 – 28524032/50
Fax: 080 – 28524191